



NOTE: TEXT IS FOLLOWED BY A *
 J11 TO J19 ARE LOCATED ON SOLDER SIDE

IDEALLY THE R2 SHOULD BE 100 OHMS AND R9 SHOULD BE 120 OHMS
 BUT FOR SHORT DISTANCE COMMUNICATION, THEY CAN BE AS HIGH AS 1K OHMS
 THEY ARE ONLY NEEDED IN THE LAST NODE.